

**INSTRUCTIONS ON HOW TO INSTALL
PRONEG ON DURST L184 AND L1840.**

- 1. REMOVE LIGHT HEAD FROM ENLARGER.**
- 2. REMOVE EXISTING CAMERA PLATE - THERE ARE 4 SCREWS – ONE IN EACH CORNER – THE CAMERA PLATE IS THE PLATE THE OLD TYPE NEGATIVE HOLDERS SLIDE ON.**
- 3. REMOVE 2 x FOUR = 8 SCREWS ON PRONEG, SCREWS ARE MARKED WITH YELLOW POINTERS. Two of the four screws are situated under the two light baffles on each side of the holder. The two last screws are situated one at each end of the light baffle.**
- 4. INSTALL BOTTOM PART OF PRONEG IN PLACE OF THE CAMERA PLATE JUST REMOVED.**
- 5. INSTALL TOP PART OF PRONEG – OPPOSITE SEQUENCE OF WHAT WAS DONE UNDER POINT 3**
- 6. RE-INSTALL LIGHT HEAD.**

THAT WAS IT – GOOD LUCK

CALL 503 846 1492 – 7AM TO 7PM – 7 DAYS A WEEK – IF YOU HAVE ANY QUESTIONS.